

ACTUALIZACIÓN FIRMWARE DEL INSTRUMENTO BLUE FORCE SMART

- Siga los pasos a continuación: 1 a 6
- Encender y conectar el BlueForceSmart al puerto USB de su PC y ejecute el Programma BlueForce:

🎽 Blue Fo	orce 3.21				7
File Verif New	fier Customer Door Tests ? Verifier				
Settin	ngs > Serial Port >		Detail		
Delet	te tests list Language >			\bigcirc	
Exit	Diagram >		100450		
			123436	Cliente	
🎽 Info	×	Ŭ.	nfo		×
Model	BlueForce SMART (art. 50V001B2)	Mo	del	BlueForce SMART (art. 50V0	001B2)
Builder	Microtronics srl	Bui	ilder	Microtronics s	h
Serial Number	04000	Se	rial Number	04000	
Calibration Date	01/01/2015	Cal	libration Date	01/01/2015	
Firmware	1.03	Fin	mware 3	1.07	
Date and time RTC		Dat	te and time RTC	02/01/15 00:5	3
	Set current date and time			Set current date and time	
Data present in database Undate database with curre	nt data	c	Data present in database	ent data	
Data of instrument connecte	ed to COM3 👻 ?	e	Data of instrument connecte	ed to COM3 👻	?
	Chiudi		opuate miorniation		Chiudi
	Update firmware WARNING!!! ensure that the power valid update file. If not performed of the instrument and require deliv you wish to continue with the firm	Ultima modifica n 02/11/2015 1628 supply to the PC is str correctly, this operatio revy of this to our servi ware update?	Tipo Dime File BIN BIN files (Chin) Apri able and that there in could impair ope cc centre. Are you s	ensione 235358 Annulla Annulla	
	6		Si	<u>N</u> o	
Update firmware		U	pdate firmwa	re X	
Updating I IMPORTANT!!	BLUEFORCE firmware ! wait for the instrument to turn off.		Update comp	pleted	
				OK	

Espere a que la terminación del procedimiento de actualización. No apague o desconecte el instrumento hasta que se complete la descarga.